noisehush
innovation you can hear

NS400
STEREO HEADSET

User's Manual

Thank you for purchasing the NoiseHush NS400 Bluetooth Sports Headset!

The NoiseHush NS400 Bluetooth Sports Headset is a cut above the rest. With its lightweight, sweat resistant, and user intuitive body, the NS400 allows you to walk, play sports, and even dance to your favorite music with ease while never missing an incoming call! The NS400 features an ergonomic neckband for optimum comfort and call easy touch functions including play/pause, call mute, volume and track control. With the best in class echo and noise cancellation technology, the NS400 delivers crystal clear conversations and superior audio quality through any Bluetooth enabled mobile phone, computer, or music player while on the go.

Please take a moment to read this manual thoroughly, and keep it for future reference. The user manual explains the features and functions of your NS400 to help ensure an optimal user experience.

To learn more about the NS400 Bluetooth Sports Headset, or other NoiseHush products, please visit www.noisehush.com

Specifications:

Bluetooth: V2.1+EDR
Transmission Power: Class 2
Bluetooth Profiles: A2DP, AVRCP, HS/HF
Frequency Response: 20Hz–20KHz
Frequency Range: 2.4GHz–2.480GHz
Transmission Distance: 10 meter
Battery: 400mAh Li-Poly

Package Contents:

- NS400 Headset
- USB Charging Cable
- Carrying Case
- User Manual



How to use the NS400

Turning ON/OFF:
To turn ON the NS400, press and hold the Multifunction Button (MFB) for 3 seconds until the blue LED turns on.

To turn OFF the NS400, press and hold the MFB for 3 seconds until the red LED flashes and turns off.

Pairing your NS400:

1. Press and hold MFB for about 7 seconds until the red and blue LED flash alternatively.
2. Using the Bluetooth menu on your device, enable searching of nearby Bluetooth devices.
3. Once the "NoiseHush NS400" is found, connect and pair to it. If your device prompts you for a password, please use "0000". For more details, please refer to your device's owner manual.
4. If the connection is successful, blue LED will flash every 7 seconds. If the pairing is unsuccessful, please turn off the NS400 and repeat Step 1.

Hands-free calling functions:

- Answer a call: Press the MFB once during an incoming call.
- Reject a call: Press and hold the MFB for 2-3 seconds during an incoming call.
- End a call: Press the MFB once during a connected call.
- Redial last number: Press and hold the MFB for 2 seconds to redial the last dialed number.

Voice Dialing:
To use this voice dialing function, your mobile phone must provide this option and corresponding voice samples must have been recorded.

1. Press MFB twice, and you will hear a short beep.
2. Say the name of the person you wish to call clearly.

Adjust Volume:
Increase or decrease volume: Press the + or – buttons to set the volume.

Play/Pause Music:
In idle state, press MFB one time to play or pause music.

Previous/Next Song:
Press the ▶▶| (Forward) button to play next song and the |◀◀ (Backward) button to play previous song.

Switch the Call Between Mobile and Headset:
Press and hold MFB for 2 seconds and you will hear a short beep. The call will be switched from headset to mobile or vice versa.

Battery and Charging Notice

We use rechargeable battery for NS400. A normal charging process takes about 2–3 hours. The red LED will turn on when charging and will turn off when charging is finished.

When battery is nearly used up, the red LED will flash every 30 seconds and there is also prompt from the headset. Please charge the headset at this time.

Always use correct AC Power Adapter to charge the headset. Using any incorrect power supply device will cause damage and void the warranty.

Warning and Cautions:

- Do not expose this unit to water, rain or moisture.
- Do not leave the unit exposed to extreme heat for long periods of time.
- Do not use the headset in situations which require special attention (e.g. in traffic or when performing skilled jobs).
- Attention—Your ears are very delicate, prolonged exposure to sound pressure levels above 85dBA can cause damage to hearing. This temporary loss of hearing can become permanent if exposure is done on a regular basis. Please protect your hearing.

ONE YEAR WARRANTY Limited Parts

Warranty Information:
NoiseHush warrants this product against defects in material and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser.

To view our warranty policy or to submit a claim, please visit www.noisehush.com.

V0712

www.noisehush.com